



QSDT8DP Alarm Recording

Prior to setting up Alarm Recording, you must set up Motion Detection.

STEP 1: Press the “Menu” Button on the front DVR panel




STEP 2: Enter Login information to access the System menu. Default User name is “admin” and default Password is “123456” (this can be punched in on the front panel of the DVR using the digital buttons and direction keys).




QSDT8DP Alarm Recording

STEP 3: On the System menu screen, select the Motion submenu using the “Enter” button on the front panel.



STEP 4: Select the channel that you want to set up motion detection for




QSDT8DP Alarm Recording


STEP 5: Put a checkmark in the box next to “Enable”



STEP 6: Move the cursor to the “Set” button next to Area and press “Enter”




STEP 7: Move the cursor to “All” and press “Enter”; if you wish to customize the motion detection area, move the cursor to “Custom” and press Enter



QSDT8DP Alarm Recording

STEP 8: If you selected “All” go to the next step; if you selected “Custom”, use the direction keys and the enter button to set the area. (The area that will set off motion detection will be clear).




STEP 9: Move the cursor to “Sensitivity” and set the detection strength.



QSDT8DP Alarm Recording

STEP 10: Move the cursor to “Save” and press “Enter”.




STEP 11: Move the cursor to the “Set” button next to Trigger and press “Enter”.



QSDT8DP Alarm Recording

STEP 12: Move the cursor to “OK” and press “Enter”.



The screenshot shows the 'TRIGGER' menu with the following settings:

Alarm out	1	2	3	4
	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>

To record	1	2	3	4	5	6	7	8
	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	9	10	11	12	13	14	15	16
	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Buzzer:


To P.T.Z CH: 1

Preset: 1

Cruise: 1

Buttons: OK, Cancel

STEP 13: Select the channels that you want to start recording once the alarm is triggered.



The screenshot shows the 'TRIGGER' menu with the following settings:

Alarm out	1	2	3	4
	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>

To record	1	2	3	4	5	6	7	8
	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	9	10	11	12	13	14	15	16
	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Buzzer:

To P.T.Z CH: 1


Preset: 1

Cruise: 1

Buttons: OK, Cancel

QSDT8DP Alarm Recording

STEP 14: Select whether or not you want a buzzer to go on once the alarm is triggered.




The screenshot shows the 'TRIGGER' menu with the following settings:

	1	2	3	4	5	6	7	8
Alarm out	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>				
To record	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Buzzer	<input checked="" type="checkbox"/>							
To P.T.Z CH	1							
Preset	1				Cruise 1			

Buttons: OK, Cancel

STEP 15: Move the cursor to the “OK” and press “Enter”.



The screenshot shows the 'TRIGGER' menu with the following settings:

	1	2	3	4	5	6	7	8
Alarm out	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>				
To record	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Buzzer	<input checked="" type="checkbox"/>							
To P.T.Z CH	1							
Preset	1				Cruise 1			

Buttons: OK, Cancel