



QSDT8DP Smart Phone Access: iPhone

Prior to setting up your phone to view your cameras, your DVR must be set up for remote viewing. The program used for accessing your DVR on your phone supports iPhone OS 2.2 or higher.

STEP 1: Go to the App Store on your iPhone




STEP 2: Click on the “Search” button




QSDT8DP Smart Phone Access: iPhone

STEP 3: In the search field, enter in “SuperCam”.



STEP 4: Select the “SuperCam” app.



QSDT8DP Smart Phone Access: iPhone

STEP 5: Click on “Free”.



STEP 6: Click on “Install”.




QSDT8DP Smart Phone Access: iPhone

STEP 7: Enter your iTunes password and click “OK”. The App will install on your iPhone.




STEP 8: Click on “SuperCam”.



QSDT8DP Smart Phone Access: iPhone

STEP 9: Click on “System Setting”.




STEP 10: Under “Server”, enter the external IP of your router. Under “Name” and “Password”, enter the login information from your DVR.



QSDT8DP Smart Phone Access: iPhone

STEP 11: Click “Live View”.



STEP 12: You can now view your cameras from your DVR.

